



Model AGT705

Max. Capacity: 300 lbs. including one person and gear

Platform Size: 18 in. x 13 in.

Weight: 54.5 lbs.

Min. Tree Diameter: 12-inches

Seat Height: 22-inches

Congratulations on your purchase of an Advanced Game Technology Global treestand! The following information is included in your instructions.

- Safety and instructions
- Warnings
- Container contents
- Assembly instructions
- Maintenance and care instructions

Warning

Maximum Weight Capacity:
300 pounds including person and gear.

DANGER:

DO NOT use this treestand without a Full Body Fall Arrest System (FAS). Failure to wear a Full Body Fall Arrest System (FAS) could result in serious injury or death.

DO NOT use before reading and understanding the instructions included with this treestand.

DO NOT use your treestand while under the influence of medication, alcohol, or drugs or if you experience dizzy spells, heart problems, or have a fear of heights.

DO NOT use this treestand during inclement weather.

WARNING:

Before each use, always inspect this treestand for undue wear, deformity, corrosion or other visible damage.



ALWAYS: Test and practice using your fixed position treestand until you are comfortable and fully understand the proper use and installation of the AGT705 ladder treestand.

Model: AGT705 Ladder Treestand

Maximum Weight Limit —300 lbs.

CARTON CONTENTS: AGT5705

1	Seat Section	Part # 660
2	Seat Section support	Part # 661
2	Platform Support Straps	Part # 662
1	Platform	Part # 663
1	Top ladder section	Part # 664
2	5-ft. Ladder Sections	Part # 665
1	Ladder Bar	Part # 666
2	Shooting Rail Support Arm	Part # 667
1	Shooting Rail Bar	Part # 668
2	16-ft. Ladder Stabilizing Straps	Part # 669
1	6-ft. Ratchet Strap System	Part # AAGH5
1	Full Body Fall Arrest System (FAS)	Part # FAS001

Hardware:

6	2-Inch Locking Pins	Part # 050
2	8mm x 2 1/2 Inch Bolts	Part # 002
4	8mm x 3 1/2 Inch Bolts	Part # 007
4	8mm x 1 3/4-Inch Bolts	Part # 005
1	8mm x 1 1/2-Inch Bolts	Part # 011
10	8mm Locknuts	Part # 003
22	8mm Steel washers	Part # 004
1	8mm Wingnut	Part # 013
4	6mm x 1 1/4-Inch Bolt	Part # 023
4	6mm Locknut	Part # 027
8	6mm Steel Washer	Part # 028

Maintenance & Care

To ensure your safety, inspect your treestand before each use. Never use the treestand if damage is detected or suspected.

Regular maintenance by the user includes, but is not limited to the following:

Tightening or replacement of hardware (specified and supplied by the manufacturer).

Replacement of rope, straps, cables, etc. (specified and supplied by the manufacturer).

Advanced Game Technology Global, Inc., LIMITED WARRANTY

What This Warranty Covers:

Advanced Game Technology Global, Inc. treestand products are covered against defects in workmanship and materials for a period of one (1) year from the original date of purchase.

Advanced Game Technology Global, Inc. will replace without charge any original part determined by Advanced Game Technology Global, Inc. to be defective under the terms of this warranty.

What This Warranty Does Not Cover:

Lost parts; accidents; malfunctions caused by alterations, improper installation, use of unauthorized parts or attachments; damages due to abuse/misuse; normal wear; excessive wear caused by owners neglect; or products that are put to commercial/rental use.

Statement of Liability


It is expressly understood that Advanced Game Technology Global, Inc.'s., liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair or replacement of any defective parts within the one (1) year time limit mentioned above. Advanced Game Technology Global, Inc. is not liable for any injury or expense, whether direct or consequential, including but not limited to loss of use, income, profit or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Advanced Game Technology Global, Inc., products. Advanced Game Technology Global, Inc., reserves the right to make alterations or modifications in its products at any time, which in its opinion may improve the performance and efficiency of the product. It shall not be obligated to make such alterations or modifications to products already in service.

Advanced Game Technology Global, Inc. treestands are delivered by Advanced Game Technology Global, Inc., with the understanding that Advanced Game Technology Global, Inc., assumes no responsibility for its resale or safe use.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. You should check the State Laws to see if they apply.

ASSEMBLY AGT705

1. To assure that all parts will fit together when assembling the top section of the ladder treestand, hand tighten all locknuts and bolts.
2. Place (1) steel washer onto each of the (4) 8mm x 3-1/2 inch bolts. Insert (2) of the 8mm x 3 1/2 inch bolts through each of the shooting rail support arms (part# 667), seat section (part# 660) and seat section supports (part# 661). Secure all bolts with (4) 8mm steel washers and (4) 8mm locknuts. (picture 1)
3. Insert the end of the shooting rail bar (part# 668) into the shooting rail support arms. Bolt the shooting rail bar and the shooting rail support arms together, using (4) 6mm x 1 1/4 inch bolts, (8) 8mm steel washers and (4) 8mm locknuts. (picture 1)
4. Bolt the platform (part# 663) to the inside of top ladder section (part# 664), using (2) 8mm x 2 1/2 inch bolts, (4) 8mm steel washers and (2) 8mm locknuts. (picture 1)
5. Insert the crimped ends of the top ladder section into the seat section supports. Secure the top ladder section to the seat section supports with (2) locking pins. (picture 1)
6. Bolt the platform support straps (part# 662) to the inside of the seat section on each side using (2) 8mm x 1 3/4 inch bolts, (4) 8mm steel washers and (2) 8mm locknuts. (picture 1)
7. Bolt the platform support straps to the outside of the platform on each side using (2) 8mm x 1 3/4 inch bolts, (4) 8mm steel washers and (2) 8mm locknuts. Hand-tighten locknuts only. (picture 1)



Set-up instructions AGT705

WARNING: Raising the ladder stand requires at least two people.

1. Attach the two 16' ladder-stabilizing straps on each side of the tree brace. Wrap the loop end of the strap around the tree brace and thread the strap through the loop. Pull the strap tight.
2. Insert the crimped end of the ladder sections together. Insert the ladder sections into the top ladder section, secure all sections using (4) locking pins.
3. With the ladder stand assembled, position the bottom ladder section 3 to 4 feet away from the base of the tree. Stand the ladder stand up against the tree so that the tree brace on the back of the seat section rests securely against the tree.
4. Level the platform by moving the bottom ladder in or out from the base of the tree. Step on the bottom ladder rung to set the ladder in the ground.
5. Attach the ladder support to the fifth ladder rung, Insert one 8mm x 1-1/2 inch bolt through the hole in the ladder support and secure with a wingnut to the ladder rung.
6. Secure the ladder support to the tree by wrapping the strap around the tree and thread the strap into the buckle on the opposite side of the ladder support. For proper threading refer to the support bar strap threading instructions. Make sure the strap is tight and the ladder support is secure to the tree.

WARNING: Make sure that the ladder support is up against the tree and the strap is tight. Failure to attach the ladder support properly could cause the ladder to fall.

7. Take one of the 16' ladder stabilizing straps that is attached to the tree brace. Walk the strap around the tree crossing the back of the tree and tie it to the ladder rung that the ladder support is attached. Repeat with the other 16' ladder stabilizing strap, crossing the strap behind the tree. The two 16' ladder-stabilizing straps will help hold the top section of the ladder stand secure to the tree as you ascend the ladder to secure the ratchet strap around the tree.

WARNING: Make sure that the ladder stabilizing straps cross behind the tree and the strap is tied tight to the ladder rung. Failure to attach the ladder stabilizing straps properly could cause the ladder to fall.

8. For proper threading refer to the ratchet strap instructions.
9. When remove the ladder stand from the tree. Never remove the ladder stabilizing straps, the ladder stabilizing straps may need to be retightened before losing the ratchet strap. To remove the ladder stand reverse the set-up process.

AGT recommended that you lubricate all hardware annually or as needed. It is recommended that you replace all hardware, chains, and cables on your tree stand with AGT replacement parts every three years.

You must replace all straps annually. Use only AGT replacement straps.

Never modify you tree stands. Modifications will void the warranties and relieve Advanced Game Technology Global Inc. from all liabilities.

Ratchet Strap Threading Instructions

1. Close the ratchet so the strap slot is accessible to thread the strap through. Insert the strap through the slot; the strap must be pulled tight before the ratchet can be secured. (picture 1 and 2)



WARNING: You must pull the strap through the ratchet tight before you use an open and close ratchet method to tighten the strap securely.

WARNING:

You must check all straps for proper threading. Refer to the instruction for each individual strap.

WARNING:

Before each use, always inspect this treestand for undue wear, deformity, corrosion or other visible damage. It is recommended that you replace all hardware (locknuts, wingnuts, bolts and support cables) every three years and (support straps) annually. It is recommended that you lubricate all hardware as needed or at least annually.

WARNING:

You must replace all straps every year; use only Advanced Game Technology Global, Inc. replacement straps. The use of any other straps will be viewed as a modification to the stand. Modifications will void the warranties and relieve Advanced Game Technology Global, Inc. from all liabilities.



Advanced Game Technology
8915 N. Pioneer Road
Peoria, IL 61615
(309) 691-2950
www.advancedgametechnology.com